


## Recommended Cameras for the "DELTA 20" using HEINE SLR Photo Adaptor

| Manufacturer | Type               | HEINE SLR Photo Adaptor |
|--------------|--------------------|-------------------------|
| Canon        | EOS 7D / 50D       | T-000.34.185            |
|              | EOS 350 D*/400 D*  |                         |
|              | EOS 450 D / 500 D  |                         |
|              | EOS 550 D / 1000 D |                         |
| Nikon        | D 40* / D 80*      | T-000.34.186            |
|              | D 40X              |                         |
|              | D 60 / D 90        |                         |
|              | D 200 / D 300 S    |                         |
|              | D 700 / D 7000     |                         |
|              | D 3000 / D 5000    |                         |
| Olympus      | E-450 / E-510      | T-000.34.187            |
|              | E-520 / E-620      |                         |

\* no longer available



## Camera setup for SLR-Adaptor

### Nikon

- ISO: 400
- Program: M
- Exposure: 1/40s
- White balance: manual

### Canon

- ISO: 400
- Program: Tv
- Exposure: 1/40s
- White balance: manual

### Olympus

- ISO: 400
- Program: S
- Exposure: 1/40s
- White balance: manual

**Canon Camera Name Chart**

| <b>Europe</b>  | <b>USA</b>    | <b>Japan</b> | <b>MPixel</b> |
|----------------|---------------|--------------|---------------|
| Canon EOS 300D | Digital Rebel | Kiss Digital | 6             |
| 350D           | Rebel XT      | Kiss N       | 8             |
| 1000D          | Rebel XS      | Kiss F       | 10            |
| 400D           | Rebel XTi     | Kiss X       | 10            |
| 450D           | Rebel XSi     | Kiss X2      | 12            |
| 500D           | Rebel T1i     | Kiss X3      | 15            |
| 550D           | Rebel T2i     | Kiss X4      | 18            |